
FLOOR 3

CALL 911



FIRE ALARM WILL SOUND AS CHIRPING ELECTRICAL HORN, STROBE LIGHT WILL FLASH.

PERSONS WITH DISABILITIES

CALL 911, REPORT YOUR LOCATION, PROCEED TO THE NEAREST EXIT OR EXIT STAIRWELL AND AWAIT ASSISTANCE.



EVACUATION SITE

SYMBOL LEGEND

EMERGENCY EGRESS PATH



FIRE EXTINGUISHER

YOU ARE HERE

ALARM PULL STATION